

Product Technical Fact Sheet

Precision Part Number: AQU-5
 Precision Description: 5-Pad Aquarium Test Strips

Application:

The AQU-5 test strips are designed for use in aquarium waters.

Instructions for Use: Follow the instructions on the label.

PL Precision
 LABORATORIES

Aquarium 5-pad Test Strip
 (Qty: 50 strips)

Dip strip into water so all pads are submersed. Swirl three times and remove. Hold strip level. Do not shake off excess water. Wait 1 minute to read results.

To convert KH and GH into ppm, multiply number in degrees by 17.8.

800-733-0266
 www.PrecLaboratories.com
 AQU-5

	1	2	3	4	5
pH Pad 1	6.4	6.8	7.2	7.6	8.0 8.4
Alkalinity KH Pad 2	0	3	6	10	15 20
Hardness GH Pad 3	0	3	7	14	28
Nitrate ppm Pad 4	0	10	25	50	100 250 500
Nitrite ppm Pad 5	0	0.5	1.0	5.0	10 25

Test Range: Varies – see label chart above
 Test Increments: Varies – see label chart above
 Accuracy: +/- ½ color chart unit

Storage Recommendations: Store in original packaging in a cool (20-30C), dry, place out of direct sunlight.

Shelf-Life: Two years from date of manufacture when stored properly in original packaging.

Interferences: None known.

Disclaimer: The AQU-5 test strips are intended for use with aquarium waters only. They should not be used in other applications.